

INSTRUCTIONS

IMPORTANT -PLEASE READ BEFORE USE

Pet Grooming Kit

EN


Please read this user manual carefully and use it correctly
(pages 1–11)

Pet Grooming Kit

JP

この取扱説明書をよくお読みのうえ、正しくお使いください(ページ 12-22)

ペット用バリカンセット



Ⓜ www.apetdola.com

✉ support@apetdola.com

Pet Grooming Kit

Product Manuals

- Safety notice 01–02
- Packing list 03
- Instructions for use 04–07
- Daily maintenance 08–10
- Product specification 10
- After-sales service 11
- About us 11

Safety Notice

Before use, please read this manual carefully and keep it properly.



Warning

- For your safety, be sure to use the power cord included in the product package.
- Please do not touch the power plug and product switch when your hands are wet, there is a risk of electric shock or product failure.
- Please do not pull the power cord and do not put heavy objects on the top of the machine.
- Do not use this product in wet places such as bathrooms near water sources, and do not inhale water or other liquids.


- Please do not inhale high–temperature items (such as cigarettes, matches, hot soot, etc.) to avoid fire.
- Do not use the product to clean up combustible liquids such as kerosene and gasoline.
- Do not use this product in (or near) environments where flammable or combustible gases , as this may cause a fire.
- Do not use products with aromatics and fragrances to filtration; such chemicals can cause fires.
- Do not use this product if the plug, power cord or the product itself is damaged.
- Please do not disassemble this product, it may seriously lead to electric




Attention

- This product is only suitable for house use, please do not use it in industrial places and outdoor places.
- Be sure to use the product in a horizontal and stable position. Failure to do may result in fire, injury or malfunction due to tipping.
- Make sure the ventilation is not blocked before use.
- Before connecting the product to the power supply, please check whether the voltage marked on the product matches the local supply voltage.
- Be sure to confirm that the filter is installed before use. The product may be damaged if it is operated without a filter.
- Children under 12 years old must be accompanied by an adult when using the product.
- Place the product and its accessories out of the reach of children and pets to avoid being swallowed by mistake.
- Please make sure the power cord is disconnected when cleaning.
- Please clean the dust cup and filter regularly, it may cause the product to malfunction.
- Do not use the product for more than 1 hour at a time to prevent the product body from overheating.
- It is slightly hot is normal when using. (The temperature is around 30–35 degrees)
- Be sure to disconnect the power when not in use.


Packing List



Fuselage
(vacuum cleaner) * 1




Accessories holder * 1



Hose * 1




Filter*1




Power cord * 1




Limit comb * 8
(3mm 6mm 9mm 12mm 15mm
18mm 21mm 24mm)



User Guide * 1



Needle comb * 1



Hair removal comb
attachment * 1



Electric clipper * 1



Cleaning brush * 1



Nozzle head * 1


Note: If you find that some items are missing from the package, please get help through customer service (support@apetdola.com) as a priority.

Confirmation before use

- Make sure the ventilation is not blocked before use.
- Be sure the filter is installed before use. If using the product with the filter removed, product damage possibility.
- Before connecting the product to the power supply, please check whether the voltage marked on the product matches the local supply voltage.



Pre-use preparation

1. Lightly place the arrow in the direction indicated, and hear a click to install successfully.




2. Align the three guide pillars of the hangers with the three holes on the chassis, and install them in the direction indicated by the arrows.

3. Align the hose with the base air outlet and hear a click to install successfully.




4. Use the attachment by connecting it to the hose. By pressing the button at the interface between the attachment and the hose, the attachment can be removed and replaced with another attachment for use.

Pay attention to the attachment when using, beware of cuts.




Instructions For Use Of Accessories

Turn on the electric trimmer



1. Press and hold the on button 3S to turn on.

Use of equipment



On/off button



MODE button

Press MODE button to switch between low, medium and high level modes.

Light up 1 light low gear
Light up 2 lights mid-range
Light up 3 lights High-grade

Use Of Accessories

1. Electric Clipper

Cutting and inhalation of pet hairs.

Note: Remember to pay attention to the edge and sharp position when using, do not use excessive force to cause skin scratches.




2. Needle comb

Can be used to clean the pet hairs on the pet.



3. Hair Removal Comb

Thinning of pet hair for grooming effect.




4. Cleaning Brush

Can be used to clean pet hair from clothes and sofas.



5.Nozzle head

Can be used to clean the hair in the crevice corners.




6.Limit comb

Limit Comb For pet hair styling, different hair combs can be replaced according to different hair styling requirements. (Optional)


Note: The limit comb is small and scattered, so please keep it properly to prevent loss when not in use.

Limit comb size: 3mm 6mm 9mm 12mm 15mm 18mm 21mm 24mm




1.Needle comb accessory assembly

Lightly loaded in the direction indicated by the arrow; disassembly method: press and hold the small button at the top of the handle to take off the attachment.



2.Hair removal attachment assembly

Lightly loaded in the direction indicated by the arrow; disassembly method: press and hold the small button at the top of the handle to take off the attachment.




Daily Maintenance

Dust cup cleaning


1. Remove the dust cup

Remove the dust cup by pressing the button at ① and lifting it slightly in the direction of the arrow.



2. Open the lid and pour out

Push the snap to open the dust cup and pour out the lint.



3. Dust cup placement

Install in the direction of the arrow and hear a click for successful installation.




Caution:

Take care to hold and put the dust cup gently; if the dust cup is cleaned after dumping the dust chips, remember to wait until the dust cup is dry before installing it, in order to prevent the motor from being damaged by water.


Electric clipper cleaning

1. Push the cutter head with force and it can be removed.




2. Suction port to remove debris at the cutter head.

3. When installing, first align 1 place, then please press can be installed.




Filter cleaning


1. Remove the dust cup and take out the filter.



2. Suction mouth to remove the residual debris.




3. Clean it up and then install the filter, install the filter back to the original place, please make sure to install the filter.



Filter sponge cleaning


1. Unplug the power, remove the dust cup and take out the filter.




2. Please wash it with water and drain it.



3. Place in a well-ventilated place for at least 24 hours to dry.



4. Install the filter sponge back to the original place after it is completely dry, and make sure to install the filter.




Caution:

- The maintenance period depends on the frequency of use, so please replace it regularly. If you use it frequently, we recommend replacing it every 3 months.
- Unplug the filter from the socket when cleaning.
- Be sure to install the filter after drying.
- Wet filters can cause electrocution and malfunction.

Power Cord Storage

Wrap and store the power cord to the bottom of the body, then snap the power plug into the chassis cable slot.



Product Specifications

Product Name: Multifunctional pet grooming kit

Voltage: 120V,60Hz(US)

Model: GK10

Material: ABS

Rated power: 350w

Suction force: 7.5KPa/12KPa/18KPa

Measured noise: 49–61dB

Dust collection cup volume: 3.2L

Power cord: 2.5m

Hose length: 1.8m

Load speed: 5500–6000r/min

Limit comb size: 3mm, 6mm, 9mm, 12mm, 15mm, 18mm, 21mm, 24mm

Fuselage weight: 1.68kg

After-sales Service

The product warranty period is 12 months from the date of purchase. Within one year after purchase, if the product fails to work properly due to its own problems, APETDOLA will provide you with replacement or free maintenance services.

How to get after-sales service?

If you have questions or need service, contact the **support@apetdola.com** for guidance.

Under the following circumstances, we will not provide repair services, whether or not within the warranty period.

a. Products not purchased directly from APETDOLA sales channels (such as personal sales, auctions, etc.);

b. The customer opens the product or attempts to modify the product;

Note: Regulations are subject to change without notice. APETDOLA reserves the right to renew the warranty as and when required. All repairs and requirements will be handled according to the latest warranty.

About Us

Within 14 days of receiving the product, you only need to register as an APETDOLA member on the official website, and the warranty period of the purchased product will be extended to 2 years. On a regular basis, we will issue various coupons to members for use when shopping.

Method:

Please log in to the following website and follow the prompts to become a member:

www.apetdola.com

How to get in touch

support@apetdola.com

※ If you are not sure how to register, you can contact our after-sales support.



ペット用バリカンセット

取扱説明書

- 安全上のご注意 12-13
- パッケージリスト 14
- 使いかた 15-18
- お手入れ 19-21
- 製品仕様 21
- アフターサービス 21-22

安全上のご注意

この取扱説明書をよくお読みになり、正しくご使用ください。
お読みになった後は、大切に保存してください。



警告

- ・電気安全を確保するために、必ず製品同梱の電源コードをご使用ください。
- ・濡れた手では絶対器具やボタンに触れないでください。（感電・故障等の原因となります）
- ・コードを引っ張ったり、本商品の上に重いものを置かないでください。
- ・浴室などの高湿な場所でのご使用は、絶対に避けてください。絶対に水やその他の液体を吸引しないでください。
- ・タバコ、マッチ、熱い灰など、燃えているもの、煙の出ているものを吸引しないでください。（火災・けが・故障等の原因となります）


- ・灯油、ガソリンなどの引火性液体を絶対に吸引してはいけません。（火災・けが・故障等の原因となります）
 - ・可燃性ガス・揮発性の液体・危険物の側や保管場所では絶対に使用しないでください。爆発や火災事故の原因になります。
 - ・香り入りのフィルターを使用しないでください。火災の原因になる可能性があります。
 - ・電源コードやプラグの損傷、本製品が損傷した場合は使用しないでください。
 - ・絶対に分解したり、改造したりしない。火災や感電、故障の原因となります。
 - ・本体の温度上昇が著しい場合、すぐに使用を中止し、アダプターをコンセントから抜いてください。
- このような場合は、本体が冷えてから涼しい場所でお使いください。吸込口、排気口をふさがないことを確認し、60 分あとに再起動してください。




注意

- ・本製品は室内使用製品です。屋外や作業場所で保管したり、使用したりしないでください。
- ・必ず水平な安定性のよい場所に設置してご使用ください。転倒による火災・けが・故障等の原因となります。
- ・吸込口、排気口を必ずふさがないでください。
- ・本製品はお住まい地域の規準に従った電圧の AC 電源をお使いください。
- ・フィルターを取り付けられていることを確認してからご使用ください。破損・故障等原因となります。
- ・12歳未満の子供が使う場合は、大人の監視が必要です。
- ・小さな子供やペットが触れるところに置かないでください。誤って部品などを飲み込まないよう、周囲の人が常に注意してください。
- ・お手入れの時は必ず電源プラグをコンセントから抜いてください。
- ・ダストカップやフィルターのゴミは、こまめに捨ててください。吸引力の低下や故障の原因になります。
- ・1時間以上長時間連続してのご使用は避けてください。
- ・使用しない場合は、安全のため電源プラグをコンセントから抜いてください。


パッケージリスト



本体＊1




付属ブラケット＊1



ホース＊1




フィルター＊1




電源コード＊




バリカン用アタッチメント＊8
(3mm 6mm 9mm 12mm
15mm 18mm 21mm 24mm)




取扱説明書＊1




スリッカーブラシ＊1



グルーミングブラシ＊1



バリカン＊1



ブラシ付きノズル＊1



すきまノズル＊1

ご注意：万一、不足しているものや破損しているものがあった場合には、support@apetdola.comまで直ちにご連絡ください。



使いかた

使用時の注意

- ・排気口を必ずふさがないでください。
- ・フィルターを取り付けられていることを確認してからご使用ください。破損・故障等原因となります。
- ・本製品はお住まい地域の規準に従った電圧の AC 電源をお使いください。



お使いになる前に

1. 矢印の方向に本体にダストカップを接続してください。
「カチッ」音がするまで確実に取り付けてください。





2. 矢印が示す場所に、ブラケットを取り付けます。

3. 本体の接続部にホースの接続部の向きを合わせてしっかり差し込みます。
ホースを外すときは、ホース取り外しボタンを押しながら抜きます。




4.付属ノズルをホースにしっかり差し込みます。ノズルを交換するときも、ノズル上の取り外しボタンを押しながら抜きます。




使いかた

バリカンの使い方



電源ボタンを約3秒間長押し、起動します。

本体の使い方



電源ボタン



MODEボタン

MODEボタンを押すごとに、弱/中/強という3つの吸引モードを切り替えます。

ライトが一つ点灯	弱モード
ライトが2つ点灯	中モード
ライトが3つ点灯	強モード

ノズルの使用

バリカン

ペットの被毛を綺麗に毛を刈れます。

先端の刃が鋭く力を入れすぎるとわんちゃん・ねこちゃんの皮膚を傷つけてしまうのでご注意ください。



スリッカーブラシ

ペットの毛並みをきれいに整えられるし、サラサラした毛を効果的に取り除けて、梳きながらマッサージもできます。

背面のボタンを押すと、毛が吸い込まれます。



グルーミングブラシ

ペットの不要なアンダーコートを除去し、れいにグルーミングできます。

背面のボタンを押すと、毛が吸い込まれます。



ブラシ付きノズル

服や家具などのすき間の清掃に便利です。

すきまノズル

家具の隙間、窓のサッシ、エアコンなどのお掃除にご使用ください。

アタッチメント

アタッチメントを使用することで簡単に毛の長さを調節することが可能です。主に3mm～24mmほどの長さに調節できるアタッチメントがあり、状況に応じて付け替えられます。

アタッチメントサイズ：3mm、6mm、9mm、12mm、15mm、18mm、21mm、24mm

スリッカーブラシの取り付け





矢印の方向に取り付けてください。

取りはずし方： ハンドル上部にある取り外しボタンを押して、取りはずします。スリッカーブラシとグルーミングブラシは同じハンドルを使えます。

グルーミングブラシの取り付け

矢印の方向に取り付けてください。

取りはずし方： ハンドル上部にある取り外しボタンを押して、取りはずします。




お手入れ

ダストカップのお手入れ


1. ダストカップを取り外す

ダストカップリリースボタン①を押して、ダストカップを取り外します。




2. ごみを捨てる

ダストカップのゴミすてボタンを押します。底ふたが開き、ごみを落とすことができます。



3. ダストカップを本体に取り付ける

ダストカップを本体に取り付けてください。




ご注意:


- ・ゴミ捨てはこまめに行ってください。
- ・運転中にダストカップを取り外さないでください。
- ・ダストカップを掃除した場合は、水洗い後は十分乾燥させてから取り付けてください。

バリカン

1. 刃を②へ押しつけて取り外します。




2. ホースの口でゴミなどを吸い出します。




3. 最後、①を合わせてから押して取り付けてください。

フィルター


1. ダストカップを取り外し、フィルターを取り外します。



2. ホースの口でゴミなどを吸い出します。




3. フィルターを軽く叩き、表裏のミゾに付着しているゴミ、ほこり、汚れを取り除きます。その後、逆の手順で部品を本体に取り付けます。



スポンジフィルター


1. 電源プラグを抜いて、ダストカップを取り外し、スポンジフィルターを取り外します。




2. 水道水による弱めの流水で、よく洗います。



3. 風通しのよい場所に置きます。1日以上置き、24時間以上かけて完全に乾燥させてください。



4. 元の位置に取り付ける前に、スポンジフィルターが完全に乾いていることを確認してください。




ご注意:

- ・お手入れ時期は使用状況により異なります。3ヶ月ごとにフィルターを交換することをお勧めします。
- ・お手入れするときは、電源プラグを抜いてから行ってください。
- ・水洗いしたあとは、よく乾かしてから取り付けてください。感電や故障の原因となります。

電源コード収納

電源コードがきちんと巻かれて、本体の下に収納されます。電源コードを底部のスロットにはめ込みます。



製品仕様

品名（型番）： ペット用バリカンセット（GK10）

電圧： JP100V;US120V

周波数： 50/60 Hz

消費電力： 350w

吸引： 7.5KPa/12KPa/18KPa

運転音（約）： 49-61dB

集じん容量： 最大3.2L

電源コードの長さ（約）： 2.5m

ホースの長さ（約）： 1.8m

回転速度： 5500-6000r/min

アタッチメント： 3mm、6mm、9mm、12mm、15mm、18mm、21mm、24mm

本体質量（約）： 1.68kg

アフターサービス

このたびは、APETDOLA製品をお買い上げいただきまして、誠にありがとうございます。

ご不安やご不明な点がある方は、いつでもお気軽にご連絡ください。

お問い合わせ

メールsupport@apetdola.com

安心な保証サービス

APETDOLA製品はお買い上げ日より1年間の安心保証を提供いたします。お使用中に不具合発生したら、いつでもお気軽に出品者までご連絡ください、無料交換対応をさせていただきます。

返品・交換・返金・修理をご要望のお客様は、必ず、事前にsupport@apetdola.comまで連絡してください。保証書として、「注文番号」が必要となります。

交換・返品のルール

返品・交換をお断りする事例

a当社取扱い製品が他所で転売されたものや、譲渡されたもの

b弊社または指定業者以外で修理、改造、分解等をされた場合

ご注意：これらの利用規約を変更または修正する権利を留保します。

会員登録

商品到着から14日以内、APETDOLA公式サイトで会員登録するだけで保証期間が24か月に延長されます。会員の皆様へお買い物の際にご利用いただける各種クーポンを定期的に配布致します。

加入方法

以下のサイトに登録し、会員登録手続きを行ってください。

www.apetdola.com

お問い合わせ

support@apetdola.com

※ご不明な場合は、お気軽にお問い合わせください。



QRコード WEBサイトに掲載する

尺寸：145x205mm

颜色：单色

材质：128g铜板纸

骑马钉装订